


Contents

Box Contents:



Instruction Manual:

- Box contents
- Product Compliance
- User Interface
- Installation
- Technical Detail
- RX1 and RX2 Configuration and System Overview
- Installers notes


Icons used in this manual:



For latest PDF Instruction Manual please go to www.speedfitUFH.co.uk

Schematics

Configured as RX1



Please note - Grey and orange wires are used for boiler switching and connected to the Boiler Thermostat terminals. If RX2 Receiver is used in conjunction with an RX1 Wireless Receiver then these connections can be discarded as there will be communication between RX1 and RX2.

Product Compliance & Safety Information

Introduction. Thank you for purchasing the Speedfit Aura JGBR System Receiver. This unit is designed to work with JG Aura range of Zigbee network products.

The JGBR can be configured as remote boiler switch or a simple single channel output to control, a thermal actuator or zone valve. Please note the two configurations above can be used together in the one system.

Product Compliance. This product is CE compliant and meets the following EC Directives: RoHS2 directive 2011/65/EU, Electro-Magnetic Compatibility directive 2004/108/EC and Low voltage directive 2006/95/EC.

These instructions are applicable to the Aura model stated on the front cover of this Instruction Manual only.

Warning. This product must be fitted by a competent person, and installation must comply with the guidance, standards and regulations applicable to the location where the product is installed. Failure to comply with the requirements of the relevant guidance, standards and regulations could lead to injury, death or prosecution.


Sources of danger. The JGBR must be disconnected from mains supply before removing the cover.

Emergency. Switch off the voltage to the individual thermostat, wiring centre or complete system.

230v AC

Warning. Always isolate the AC Mains supply before installing or working on any components that require 230v AC 50Hz supply.


Configured as RX2



Reset Button - If for any reason the system receiver stops operating, press reset and check system operation.

Replacing the System Receiver - If for any reason the system receiver needs to be removed/replaced, press the delete from network button.


System Overview



System Overview - Aura System Configured as RX1

The unit can be switched internally to use one of two channels, RX1 (boiler receiver) or RX2 (single room receiver). Ensure the unit is not powered during setting of the RX1/RX2 slide switch.

The unit is supplied with the switch in the RX1 position (Boiler Receiver). In this mode, the unit can be wired to the boiler to switch it on or off using the wireless signals it receives from other Aura products on the Aura Zigbee network.



System Receiver configured to boiler receiver RX1. Refer to reverse side for wiring.

User Interface


- 1** **AUTO** - The bottom slide switch is not active. System receiver output will switch on and off in relation to the command from the Aura transmitter. The bottom slide switch is active.
- 2** **RED led only in AUTO** - There is no output from the receiver.
- 3** **RED and Green LED in AUTO** - There is an output from the receiver. The device that the receiver is connected to will be switched on.
- 4** **Manual** - System receiver output is controlled by the bottom slide switch. Either permanently ON or OFF. The LED status in manual is the same as AUTO.

System Overview - Aura System Configured as RX2

With the unit is switched to RX2, the unit will act as a single room receiver. Switching of the unit will be controlled by a paired Aura JGSTATW1/JGSTATW2 Thermostat. Depending on its intended use, the unit can be used to switch a motorised valve, thermal actuator or pump.

As well as being used in this way, the RX2 can be used in conjunction with another unit set up as an RX1 (Boiler receiver). When there is a call for heat from the thermostat paired to the RX2 both of the wireless receivers will operate turning on both the boiler and the motorised valve / pump.

Please note: Only one RX1 and one RX2 can be used as part of a network.



System receiver configured as stand alone receiver RX2. Refer to reverse side for wiring.